### **STC** SAFETY TRAINING CENTER safetytrainingcenter.org



### ASBESTOS ABATEMENT CONTRACTOR/SUPERVISOR REFRESHER COURSE SCHEDULE



#### CONTRACTOR/SUPERVISOR REFRESHER COURSE SCHEDULE

- 8:00-9:00 Course Overview and Objectives
  9:00-10:15 Contractor/Supervisor Refresher Discussion Questions Hand-Out: Course Participants to Complete
  10:15-10:30 Break
- 10:30-11:15 Contractor/Supervisor Refresher Discussion Questions (Continued) Hand-Out: Course Participants to Complete
- 11:15-12:00 Discussion Questionnaire Review
- 12:00-1:00 Lunch
- 1:00-2:30 Discussion Questionnaire Review (Continued)
- 2:30-2:45 Break
- 2:45-3:00 Discipline Specific Review, Questions, and Answers
- 3:00-4:00 Contractor/Supervisor 50 Question Course Certification Examination



#### REFRESHER CONTRACTOR/SUPERVISOR REVIEW QUESTIONS

#### **BACKGROUND INFORMATION ON ASBESTOS**

1.	Asbestos is a It is distinguished					
	from other by the fact that its crystals form					
	long, thin fibers.					
2.	is the most commonly used asbestos in					
	buildings in the US, and is the only type found in the					
	group					
3.	Which of the following types of Asbestos are from the Amphibole group?					
	Anthophyllite Amosite					
	Tremolite					
	Actinolite					
4.	The EPA says Asbestos Containing Materials are materials containing					
	asbestos. OSHA considers even a amount as					
	Asbestos containing Material.					
5.	ACM that can easily be pulverized, crumbled or reduced to powder under hand					
	pressure is called					
6.	is the type of asbestos that is difficult to wet.					
7.	Asbestos was used in over different products.					

2

8. During asbestos building inspections, ACM is place into three (3) categories.

is ACM sprayed or troweled on surfaces (walls, ceilings, structural members) for acoustical, decorative, or fireproofing purposes. This includes plaster and fireproofing insulation.

9. \_\_\_\_\_\_ is used to inhibit heat transfer or prevent condensation on pipes, boilers, tanks, ducts, and various other components of hot and cold water systems and heating, ventilation, and air conditioning (HVAC) systems. This includes pipe lagging; pipe wrap; block, batt, and blanket insulation; cements and "muds;" and a variety of other products such as gaskets and ropes.

- 10. \_\_\_\_\_\_ is other, largely non-friable products and materials such as floor tile, ceiling tile, roofing felt, concrete pipe, outdoor siding, and fabrics.
- 11. \_\_\_\_\_ (PLM) is the type of "Bulk Sample" analysis used to determine the type and percent of asbestos in

materials.

- 12. In the past, the individuals working with asbestos was during mining, manufacturing and installation. Today individuals working with asbestos are typically involved in
  - &\_\_\_\_\_.



#### HEALTH EFFECTS OF ASBESTOS EXPOSURE

- 1. \_\_\_\_\_ is caused from increased exposure to asbestos and results in scarring of the lower respiratory tract.
- 2. Scarring that occurs in the upper respiratory tract from asbestos exposure and increased exposure to other carcinogens *(like cigarettes)* increases the exposed person's chance of contracting

by \_\_\_\_\_\_to \_\_\_\_\_\_times that of a non-exposed person that is also a non-smoker.

- 3. \_\_\_\_\_\_ is a cancer of the chest cavity lining, and can also occur in the abdominal cavity. Studies indicate that Crocidolite asbestos exposure is more closely linked to this disease than the other types of asbestos.
- 5. The typical "latency" period for contracting asbestos related diseases is approximately \_\_\_\_\_\_ to \_\_\_\_\_ years.

#### PROTECTING THE WORKER: RESPIRATORS & PROTECTIVE CLOTHING

 According to OSHA's 29 CFR 1926.1101, persons performing Class I removal operations, and no negative exposure assessment was performed, the type of respirator that is required for this activity is \_\_\_\_\_.

- 2. List the 3 Items that need to be identified before using an APR?
- 1. 2.\_\_\_\_\_ 3.\_\_\_\_\_ 3. High Efficiency Particulate Air filters (HEPA) are capable of filtering \_\_\_\_\_ of all particles greater than\_\_\_\_\_microns in diameter. Respirator Cartridge filters are the same but are labeled\_\_\_\_\_. 4. Quantitative or qualitative fit testing identifies a mask's -\_\_\_\_\_. Which multiplied by the PEL will give you the mask's 5. According to OSHA's 29 CFR 1910.134, before an employee can be fit tested on a tight fitting respirator, they shall be involved in a \_\_\_\_\_ program. 6. A "User Seal Check" shall be performed \_\_\_\_\_\_a person puts on a tight fitting respirator. 7. The abatement workers will remove their \_\_\_\_\_ in the equipment room and their \_\_\_\_\_ in the shower of the personal decontamination unit. ESTABLISHING A TYPE "C" SUPPLIED AIR SYSTEM
- OSHA has designated atmospheres with less than \_\_\_\_\_ oxygen, as oxygen deficient.

- Type "C" supplied air respirator systems shall have a continuous and sufficient supply of Grade \_\_\_\_\_\_ air.
- 3. Maximum hose length on a Type "C" supplied air respirator system shall not exceed feet.

4. When anyone is on air the supply must be monitored by a \_\_\_\_\_\_.

#### ESTABLISHING A MEDICAL SURVEILLANCE PROGRAM

- 1. All individuals listed in the employer's medical surveillance program must have a physician's statement based on an examination or survey initially and
- According to OSHA's asbestos in construction standard, employees must be involves in a medical surveillance program if they are assigned to an area above the \_\_\_\_\_\_, or the \_\_\_\_\_.
- Medical records must be kept by the employer \_\_\_\_\_ years plus the employee's term of employment.
- 4. Check what is required by OSHA as part of a medical surveillance program.

General Physical	Pulmonary Function Test
Blood Test	Urinalysis
Chest X-Ray	Biopsy
OSHA Questionnaire	Physician's Opinion

#### PRE-WORK ACTIVITIES AND CONSIDERATIONS

1. Prior to set-up of the work area, the contractor/supervisor should \_\_\_\_\_

existing damage for documentation.

- 2. An \_\_\_\_\_\_ should be hired to establish temporary electrical power to the work area.
- For tape adherence and to minimize water damage due to holes created in the floor poly, a good \_\_\_\_\_\_ should be performed in the work area.
- Bulk sample reports should indicate the \_\_\_\_\_, and \_\_\_\_\_, and \_\_\_\_\_\_
   of asbestos in the materials to be removed.
- 5. A work area that is 100' x 80' x 9' = \_\_\_\_\_ ft<sup>3</sup> . \_\_\_\_ negative air machines rated at 1500 cfm will be needed to change the air 4 times per hour.
- 6. List the 4 response actions for Asbestos under AHERA.
- 1. \_\_\_\_\_.2. \_\_\_\_.

3. \_\_\_\_\_.4. \_\_\_\_\_.

#### **GLOVE-BAG TECHNIQUES FOR REMOVAL OF PIPE INSULATION**

- 1. Gove-bags shall be made with at least \_\_\_\_\_ mil poly.
- According to OSHA, glove-bag procedures shall not be performed on pipes where the metal temperature exceeds \_\_\_\_\_\_° F.
- All glove-bags shall be sealed air tight and \_\_\_\_\_\_ for leaks prior to ACM removal.
- 4. Glove-bag Techniques use a \_\_\_\_\_ decon involving a HEPA Vacuum, but you must provide the means for an \_\_\_\_\_ decon shower.

#### **PREPARING THE WORK AREA & ESTABLISHING THE DECONTAMINATION UNIT**

- The outer layer of plastic sheeting sealing all openings to the work area is known as \_\_\_\_\_\_barriers.
- State of the art techniques for setting up the work area recommends \_\_\_\_\_\_ layers of 6 mil poly for floor barriers and \_\_\_\_\_\_ layers of 4 mil poly for wall barriers.
- 3. Floor poly should extend up on the wall and all seams should overlap approximately

\_\_\_\_\_ inches.

- 4. The 3 primary chambers of a decontamination unit are: \_
  - 1.\_\_\_\_\_
  - 2.\_\_\_\_\_
  - 3.\_\_\_\_\_
- 5. Respirators are removed in the \_\_\_\_\_\_ of the decon unit.
- 6. Place the following in order for typical set-up of the work area:
  - Conduct Walkthrough Survey of the Work Area
  - \_\_\_\_\_ Cover and Seal Stationary Items with Polyethylene
  - \_\_\_\_\_ Secure the Work Area
  - \_\_\_\_\_ Locate and Lock Out the Electrical System
  - \_\_\_\_\_ Clean/Remove Non-Stationary Items from the Work Area
  - \_\_\_\_\_ Shut Down/Modify the HVAC
  - \_\_\_\_\_ Establish a Waste Load-Out Area
  - \_\_\_\_\_ Establish a Decontamination Unit
  - \_\_\_\_\_ Post Warning Signs
  - \_\_\_\_\_ Apply Critical Barriers



#### 7. List in order of use the 4 OSHA Controls.

 1.\_\_\_\_\_.
 2.\_\_\_\_\_.

 3.\_\_\_\_\_.
 4.\_\_\_\_\_.

#### **CONFINING AND MINIMIZING AIRBORNE FIBERS**

- OSHA class I work areas require contractors to use manometric measurements that prove pressure differential at \_\_\_\_\_\_ inches of a water column, inside vs. outside the work area.
- 2. Amended water is a mixture of water and a \_\_\_\_\_\_.
- 3. Negative air units consist of a \_\_\_\_\_\_ stage filtration system.
- OSHA class I work requires the air to be completely changed \_\_\_\_\_\_ times per hour.
- The use of a negative pressure enclosure system for asbestos abatement is considered an \_\_\_\_\_\_ control.

#### **SAFETY & HEALTH CONSIDERATIONS OTHER THAN ASBESTOS**

- Straight or extension ladders being used to access elevated surfaces must have a lean ratio at approximately \_\_\_\_\_\_ to \_\_\_\_\_ and extend at least \_\_\_\_\_\_ feet above the point of access.

Scaffold erection, alteration and disassembling must performed under the direction of a scaffolding \_\_\_\_\_\_.
 Free standing mobile scaffold's working height cannot exceed \_\_\_\_\_\_ times the minimum base dimension, unless secured by guys and/or ties.
 Name the Fire Extinguisher Classification: Class A – \_\_\_\_\_ Class C – \_\_\_\_\_

Class B – \_\_\_\_\_ Class D – \_\_\_\_\_

- In case of fire, inclement weather, or other emergencies, contractors are required to have an \_\_\_\_\_.
- Of all heat related medical issues, \_\_\_\_\_\_ is the most severe.

#### **CLEANING UP THE WORK AREA**

- The discussion on final cleanup applies to the phase of the project in which all of the \_\_\_\_\_\_ asbestos-containing material has been removed from the substrate and the substrate has been cleaned and wet wiped.
- A waiting period is typically done on school projects to allow surfaces to dry and fiber dust to \_\_\_\_\_.
- If visible dust and/or debris is identified during the final visual inspection, the area must be \_\_\_\_\_\_ and \_\_\_\_\_

prior to final clearance air sampling.



#### WASTE DISPOSAL REQUIREMENT

- Minimum requirements for asbestos waste being deposited in an EPA approved landfill are that the material must be \_\_\_\_\_\_ wet and in containers that are \_\_\_\_\_.
- 2. Containers of asbestos waste must have at least 3 pieces information on them:

#### SAMPLING & ANALYTICAL METHODOLOGY

- 1. Asbestos bulk sample analysis is known as \_\_\_\_\_
- Anyone taking bulk samples in a school, industrial facility, public or commercial building must be \_\_\_\_\_.
- 3. OSHA's 8 hour TWA permissible exposure limit to asbestos is \_\_\_\_\_\_ fiber/cc.
- 4. OSHA's excursion limit (30 minute peak exposure) is \_\_\_\_\_\_ fiber/cc.
- 5. AHERA's final clearance level under PCM analysis is \_\_\_\_\_\_ fiber/cc.
- The use of a leaf blower prior to collecting final clearance air samples is known as \_\_\_\_\_\_
   \_\_\_\_\_\_\_\_\_ sampling.

7. The type of final clearance analysis required for school projects involving the removal, encapsulation and/or enclosure of greater than \_\_\_\_\_\_ sq. ft. and/or

linear ft. is known as \_\_\_\_\_\_.

 of each job task on an abatement site should be monitored with personal air pumps.

#### POST REMOVAL LOCKDOWN PROCEDURES AND ASBESTOS SUBSTITUTES

- It is assumed that a small amount of microscopic asbestos fibers will remain in the work area even after a visual inspection. School projects and some Project Designers will require a spray-applied \_\_\_\_\_\_ encapsulant to be used.
- All materials chosen for lockdown, replacement, and re-insulation should be checked for \_\_\_\_\_\_.

#### **CONTRACT SPECIFICATIONS**

- The \_\_\_\_\_\_ in the contract specifications will include the description of ACM locations and quantities to the extent they have been determined (usually also provided on drawings), the type of abatement procedures to be used in a particular area, timeframe for project completion, and any restoration requirements that may be necessary.
- All contract documents should be reviewed by a \_\_\_\_\_\_ before approval and submission.

 Contract specifications that are specific in regards to labor, materials or methods are know as \_\_\_\_\_\_ specifications.

#### LEGAL AND INSURANCE CONSIDERATIONS

- 1. There are three areas of potential liability for contractors. Regulatory, Civil and
- 2. What are the two types of insurance coverage required by the abatement industry for asbestos abatement contractors?

3. An insurance policy that will cover the policy holder years later even if the injured party no longer works for the contractor is known as \_\_\_\_\_\_

\_\_\_\_\_policy.

- 4. Traditionally, two types of bonds, \_\_\_\_\_
  - & \_\_\_\_\_\_ have been required in the construction

industry to protect the owner or lender against the contractor's financial default.



#### **REGULATORY UPDATE**

Write down any new information you've learned for the following regulatory agencies:

OSHA:

EPA:








